



## Part# 543

### Heavy Duty Floor Stop

No exposed fasteners. For use in high vandalism or security areas. For Mounting, drill 1" x 2-1/2" deep hole - fill with anchoring grout

---

**Size** 2" Diameter Base x 3-1/2" High

---

**Material** Black Rubber Bumper

---

**Standard Fasteners** 5/8 x 2-1/2" mounting bolt

---

Copyright ©2026 Burns Manufacturing Inc. All rights reserved.  
Reproduction in whole or in part without the express written permission of  
Burns Manufacturing Inc. is prohibited.

2001 Lowell Avenue, Erie, PA 16506  
Phone: 800.519.2610 • Fax: 800.432.8767  
Website: [www.burnsmfg.com](http://www.burnsmfg.com)  
Email: [burnsmfg@burnsmfg.com](mailto:burnsmfg@burnsmfg.com)